

LS4G Kit-CN

快速安装指导

04
2024-01-25



说明
NOTE

•

•

LTE

02 应用场景

03 安装与调测



说明
NOTE

4G


2.

5PIN-USB
5PIN



3. 4G

逆变器USB接口



设备上电

1. 4G

2. 4G

4G		4G					
				2			
		-		-			
		0.2s	1.8s	2			
		1.8s	0.2s	2			
		1.8s	0.2s				
		0.125s	0.125s				
		0.2s	8s	2	SIM	SIM	SIM SIM
		• 1.8s	0.2s	4			
		• 0.2s	1.8s				

04 设备更换

1. 4G

4G

2. 4G

3. 4G

4.

